


Rio

Wardrobe



Assembly Instructions

Conforms to EN 14749:2016+A1:2021

Tutti Bambini. 1068 High Road, Whetstone, London, N20 0QP

t: +44 (0) 208 368 5800


e: support@tuttibambini.com

www.tuttibambini.com

Rio

Wardrobe

211330



IMPORTANT: RETAIN FOR FUTURE REFERENCE.
READ CAREFULLY

Hello,

PLEASE READ THIS LEAFLET BEFORE ASSEMBLY

Dear Customer,

Thank you for buying Tutti Bambini furniture.
Follow the instructions carefully and check that you have all the elements including the fittings before attempting assembly. If there are any missing or damaged parts, please inform us before you start the assembly. **WARNING:** installation shall be carried out exactly according to the manufacturer's instructions otherwise a safety risk can occur if incorrectly installed. Please note that incorrect assembly of your furniture will not be a basis for a claim against the product being damaged.


In the unlikely event that your furniture is found to be faulty, we ask that you send an email to:
support@tuttibambini.com with the following information that can be found on the white label on the outside parcel.

- Name
- Postcode
- Contact telephone number
- Sales order number (found on white label)
 - Product name & colour
 - Damaged part number
- A photo or video of the damaged part






Tutti Bambini guarantee your product against faulty manufacture for a period of 12 months from date of receipt of purchase. This does not affect your statutory rights






Team Tutti




Parts List




Hardware List

ID# A	 15x11.5mm 2pcs for replacement	Qty 51 pc
ID# B	 6.5x40mm 1pcs for replacement	Qty 50 pc
ID# C	 wooden dowel	Qty 18 pc
ID# D	 Hinge	Qty 6 pc
ID# E		Qty 8 pc


ID# F		Qty 2 pc
ID# G	 Ø4x20mm	Qty 2 pc
ID# H	 Ø4x12mm	Qty 2 pc
ID# I	 Ø3.5x14mm	Qty 48 pc
ID# K	 Handle	Qty 4 pc

ID# M		Qty 2 pc
ID# N	 M4x16mm	Qty 1 pc
ID# O	 200x30mm	Qty 1 pc

Assembling into wardrobe




1



Assemble pins Bx45 and dowels Cx18. Assemble hanging rail support Fx2 with I x 4.


2



A x 7 PCS



Assemble top rail and back frames with cams 7 x A.

3




Insert back panel part 11 to back frame.


Assembling into wardrobe




Assemble bottom panel part 6 using 4 x A.
Attach bottom rail part 8 to part 6.



Assemble part 1, 3, 4, 6, 7, 8 to left side panel using cams 13 x A.




Assemble right side panel part 7R
using cams 13 x A.



Assemble part 9 using cams 4 x A.

Assembling into wardrobe




8



Step 9.3
With two people,
tilt wardrobe gently
to upright position

Step 9.2
Rotate the wardrobe
for 90° to lie down
on the floor

Step 9.1
Lock all the hardware





9





Assemble door hinges D x 6 using I x 36.
Attach door handles K x 2 using G x 2.
Assemble hanging rail.

10





Step 2




Assemble two drawer sides to drawer back
using 4 x A locking nuts
Slide drawer bottom into the grooves

11




Assemble drawer front with A x 4 pcs.
Assemble drawer handles K x 2 with H x 2.

Assembling into wardrobe




12



Slide drawer into wardrobe.


12




O x 1 PC M x 1 PC N x 1 PC E x 8 PC I x 8 PC

Assemble anti falling hardware M x 1, N x 1, O x 1. Assemble back panel buckle E x 8 using I x 8.

13



14



Fittings to attach the strap to the wall are not provided and suitable fittings for the wall type should be used.

Caution: The drawer is not provided with end stops that prevent it from being pulled out of the unit

Safety advice and maintenance

IMPORTANT! KEEP FOR FUTURE REFERENCE: READ CAREFULLY


1. WARNING: Never leave your child unattended. The safety of your child is your responsibility.
2. WARNING: Do not allow children to climb on or in the wardrobe..
3. WARNING: Make sure the wardrobe is situated on a clear firm and level surface.
4. WARNING: Do not use the wardrobe if it is damaged or broken or there are parts missing.
Use only spare parts approved by Tutti Bambini.
5. WARNING: Do not place the wardrobe near the vicinity of open fires or other surfaces of strong heat, such as gas or electric fires.
6. The wardrobe can be cleaned with a clean damp cloth. Do not use aggressive cleaning agents such as bleach or strong detergents.
7. Check on a regular basis that all fittings and screws are correctly tightened and are not damaged.
Loose screws can pinch parts of the body and clothing resulting in the risk of strangulation.
8. Do not twist or pivot the wardrobe, if the wardrobe is to be moved always lift with at least two people.
9. WARNING: In order to prevent overturning this product must be used with proper wall attachment devices.
10. Any additional or replacement parts are obtained from the Tutti Bambini or its distributor.

Product development dictates that components may occasionally differ from the ones shown in the diagrams of these instructions. The right to change the specifications and design of the furniture without prior notice remains with the manufacturer.

Guarantee

All our products are produced from the finest quality materials and are manufactured under the strictest quality controls. We guarantee all our products or parts thereof against faulty manufacture for a period of one year from date of purchase. This guarantee is not effective against accidental damage or damage caused by incorrect use or neglect. This does not affect your statutory rights.

HINGE ADJUSTMENT INSTRUCTIONS



MOVING DOOR UP OR DOWN

Loosen top and bottom adjusting point screw on all hinges, push hinge up or down depending on door alignment then tighten screws and add fixed point screws.



MOVE DOOR LEFT TO RIGHT

Turn adjusting screw clockwise to move door to the right. Turn screw anticlockwise to move door to the left.



MOVING DOOR IN OR OUT

Loosen screw on all hinges, move door to desired point, then tighten all screws.

www.tuttibambini.com

Follow us    

TUTTI
bambini 

[illegible]

Join Us



Follow us on Facebook
TuttiBambiniUK



Follow us on Twitter
TuttiBambiniUK



Follow us on Instagram
TuttiBambiniUK



www.tuttibambini.com